



**FLOOR ASSEMBLY**  
**30 MIN. FRR.**



- EXISTING PLYWOOD, OSB, OR WAFERBOARD SUBFLOOR
- WOOD JOISTS OR WOOD I-JOISTS SPACED NOT MORE THAN 610 mm O.C.
- SOUND INSULATION (OPTIONAL)
- RESILIENT METAL CHANNELS SPACED 610 mm O.C.
- ONE LAYER 12.7mm TYPE X/C GYPSUM BOARD

**FLOOR ASSEMBLY**  
**15 MIN. FRR.**



- EXISTING PLYWOOD, OSB, OR WAFERBOARD SUBFLOOR
- WOOD JOISTS OR WOOD I-JOISTS
- ONE LAYER 12.7mm TYPE X/C GYPSUM BOARD

THE FOLLOWING IS REQUIRED:

- A SMOKE ALARM IS TO BE INSTALLED:
- a) ON EACH STOREY, INCLUDING BASEMENTS
  - b) IN EACH SLEEPING ROOM
  - c) IN THE HALLWAY(S) ADJACENT TO THE SLEEPING ROOMS
  - d) IN ALL COMMON AREAS

ALL SMOKE ALARMS SHALL HAVE A VISUAL SIGNALLING COMPONENT (STROBE) AS PART OF THE SYSTEM (EITHER COMBINED OR SEPARATE)

ALL SMOKE ALARMS IN BOTH SUITES MUST BE INTERCONNECTED

A CARBON MONOXIDE ALARM SHALL BE INSTALLED ADJACENT TO EACH SLEEPING AREA IN THE SUITES (EITHER COMBINED OR SEPARATE)

**INT. PARTITION WALL**  
**30 MIN. FIRE SEPARATION**



- ONE LAYER OF 12.7 mm GYPSUM BOARD
- 2"X4" @ 16" O.C. WOOD STUDS W/ 6 MIL POLY UNDER BOTTOM PLATE
- SOUND INSULATION TO FILL STUD CAVITY
- ONE LAYER 12.7mm GYPSUM BOARD

PROJECT: Accessory Apartment Guide	WALL AND FLOOR ASSEMBLY SECTIONS
ADDRESS:	DRAWN BY
	PAGE NO.